

IMPORTANT!

Clean (or replace) the Sponge!



HOW TO CLEAN

Multi-cyclone



clean
with water



clean
or replace



shake out
or replace



HOW TO CLEAN

Dust bag



clean
with water



clean
or replace



shake out
or replace



HOW TO CLEAN

Brush roll



Clean, remove tangled hairs

SCAN
ME



Order **Spare parts:**
www.trisaelectronics.ch